

Knockdown Dimensions:  
89.5" x 47" x 17" (L x W x H)  
(PALLET INSIDE)  
Container Shipping (Tare)  
Weight: Approximately 175 l



**Victory  
Packaging**

We are *Architects* of Packaging Solutions

# CORRcrate Assembly Sheet



## Assemble CORRcrate

1. Open Corrcrate take out the two poly bags
2. Open one poly bag and spread it out on the ground
3. Place bottom skid on top of bag with door flap open
4. Place first side at one end and place 2nd side at other end leaving door open for loading
5. Place top portion on top with door flap open and load container
6. Upon finishing, slide door down the side, pull door flaps for top and bottom closed.
7. Place marking on container
8. Pull bottom bag up around container and tape to the top
9. Put second bag over container put three steel bands two over top and one around middle



Pull down top  
poly bag and  
tape at the  
bottom

Pull up bottom  
poly bag and  
tape at the top

**888.261.1268**

[moversales@victorypackaging.com](mailto:moversales@victorypackaging.com)